

## **ATTENTION!**

As a result of printing error in the previous version of the installation instructions, installation kit were added redundant washers on the bolts, which can not be used during installation.

Washers should be used only on U clamps and the M8x30 mm bolt connecting the right and left piping at the top of the front part (point 9).

Other bolts used in installation does not require washers. From the set should stay unused 3 washers.

Correct installation instruction has been attached to this explanation.

## **UWAGA!**

W wyniku błędu w pierwotnym druku instrukcji instalacji, do zestawu instalacyjnego zostały dodane zbędne podkładki na śruby, których nie można użyć w trakcie instalacji.

Podkładki należy zastosować jedynie do obejm typu „U” oraz śruby M8x30 mm łączącej prawe i lewe orurowanie w górnej przedniej części (punkt 9).

Pozostałe śruby używane do montażu nie wymagają podkładek. Z zestawu powinny zostać niewykorzystane 3 podkładki.

Poprawna instrukcja instalacji została dołączona do niniejszego wyjaśnienia.

