

# KAWASAKI KLE 650 (07-10)

## W skład zestawu wchodzi:

1. Orurowanie lewe.
2. Orurowanie prawe.
3. 2 uchwyty typu „U” wraz z podkładkami i nakrętkami
4. 1 śruba M10/80 mm wraz z podkładką i nakrętką (prawa)
5. 1 śruba M10/100 mm wraz z podkładką i nakrętką (lewa)
6. 1 podkładka dystansowa 30 mm

PL

## The set includes:

1. Right piping
2. Left piping
3. 2 "U" clamps with the washers and nuts
4. 1 M10/80 mm bolt with a washer and nut (right)
5. 1 bolt M10/100 mm with a washer and nut (left)
6. 1 spacer sleeve 30 mm

EN

PL

Orurowanie powinno być zakładane tylko przez osobę wykwalifikowaną. Należy zwrócić szczególną uwagę na wiązki elektryczne, przewody hamulcowe oraz przewody gumowe chłodzenia silnika tak, aby nie były przyciśnięte lub nie tarty podczas eksploatacji o gmole z powodu źle przeprowadzonego montażu orurowania. Całość orurowania założyć swobodnie dopiero na końcu skręcić docelowo.

1. Zdemontować oryginalną śrubę M10 (Rys. 1 pkt. 1).
2. Przełożyć przez ramę motocyklową obejmę typu „U” bez nakrętek znajdującą się w zestawie (Rys. 2 pkt. 2).
3. Zamontować prawe orurowanie:
  - w pkt. 2 Rys. 2 obejmą typu „U” przełożoną już wcześniej,
  - w pkt. 3 Rys. 1 uchwytem orurowania na ramę,
  - natomiast w pkt. 1 Rys. 1 przykręcić z dłuższą śrubą M10/80 mm z zestawu.
4. Tą samą czynność powtórzyć z lewej strony lecz w pkt. 4 Rys. 3 wymienić oryginalną śrubę na śrubę M10/100 mm wraz z podkładką dystansową 30 mm z zestawu (Rys. 4).
5. Dokręcić całość orurowania docelowo.

EN

Piping should be installed only by a qualified person.

Pay particular attention to the electric beams, brake hoses and rubber hoses for engine cooling, so that they are not pinched or they doesn't chafe during operation due to wrong installation of piping.

During installation it is recommended to set up piping freely.

1. Remove the original bolt M10 (pkt. 1 Fig. 1).
2. Put on the motorcycle frame the U clamp from the set (without nuts) (Fig. 2 pkt. 2).
3. Install the right part of piping:
  - in pkt. 2 Fig. 2 fix it to already installed "U" clamp,
  - in pkt. 3 Fig. 1 fix the piping to the frame by handle,
  - in pkt. 1 Fig. 1 bolt it using the longer M10/80 mm bolt from the set.
4. Repeat the same steps on the left side, but in pkt 4 figure 3 replace the original bolt to the M10/100 mm bolt with a 30 mm spacer sleeve from the set (see Fig. 4).
5. Tighten all the piping.

[www.heed.com.pl](http://www.heed.com.pl)

Instrukcja montażu gmoli dla / Crash bars installation instruction for

# KAWASAKI KLE 650 (07-10)

